



CROSS HIT DELINEATOR INSTALL GUIDE

11 Boeing Place, Mount Maunganui 3116 Ph: 07 575 0505

2/11 March Place, Belfast, Christchurch 8051 Ph: 03 323 7507

Email: admin@trafficsigns.co.nz www.trafficsigns.co.nz PO Box 4366, Mount Maunganui South 3149

CROSS HIT DELINEATOR POST NZ Pat App. No. 729609 (Int. Pat. Pending)

- A clean, dry surface is required. Sweep or blow off the area where the base will be installed using the broom or blowgun to remove gravel, sand or other debris.
- For optimum performance, the recommended installation temperature is 10 degrees C or above. In lower temperatures the bases and pads can be warmed to this temperature prior to use.
- Remove the slip sheeting from one side of the Butyl Pad and place it on the ground with the exposed surface facing up.
- Set the X-Hit base on the Butyl Pad, centering it within the edges of the pad.
- Step on the base to secure it to the pad. Lift the base and remove the remaining slip sheet from the other side of the pad.
- Place the base in position making sure it is oriented properly. The base has arrows on the base which align with the flow of traffic. The locking pins on the base should be oriented perpendicular to the direction of traffic.
- Either Slowly drive the vehicle up onto the base and stop so one of the front wheels is directly on top of the base or Stand and put pressure on the base Remain in this position for at least 15 seconds to "set" the base.

